



K HERO MELODY INSTRUCTION MANUAL



Power Button

Click: Pause/ Unpause Music,

Hold for 3 Seconds: Turn on/off the unit,

Double Click: Turn on/off Duet mode,

M Button

Short Hold: Switch between Line In/ Bluetooth mode.

Long Hold: Change LED light mode

Volume Button

∧: Short hold for mic volume, long hold for speaker volume.

∨: Short hold for mic volume, long hold for speaker volume.

Magic Mic Button

Click: Switch between different voice effects.

Double click during default voice mode: Vocal Cancellation

5V Charging/AUX: By using a cord during Line In mode., It is possible for voice recording.

3.5mm Headphone Connection: For connecting to headphones,

Note: Volume can not be altered during LINE In mode.

Product	K Hero Karaoke Microphone
Model	Melody
Bluetooth	Bluetooth 5.0
Power	5W
Weight	270 Grams
Dimension	210mm* 87mm
Material	Cotten + ABS
Battery	1200 mah
Charging	DV0.5A

Connect To External Device

1. Press power button for 3 seconds, indicator light will start to flash blue.
2. On your smart device. Search & Connect to "K Hero Melody" in bluetooth devices.
3. A beep will occur when the device is connected, The indicator light will stay solid blue.

Note: Melody can only be connected to one device at a time, to connect to a new device please disconnect from the original device first.

Charging

Indicator light will stay solid red during charging, it will disappear when full charged.

When the unit has low battery left, it will play a warning sound 3 times before shutting off.

Please only charge by using the appropriate DC-5V charging adapters. Incorrect adapter used could cause harm to the unit.